



Glove Sizing

It is very important that the correct glove size is provided and worn and clear guidance is provided to ensure that sizing is right first time. Two measurements are required to establish the correct size – the hand circumference (A = right hand palm down, fingers together, across knuckles) and length (B = distance between wrist and tip of middle finger). Measurements given in mm



Glove sizes	6	7	8	9	10	11
Measurements in mm						
Min. length of glove	220	230	240	250	260	270
Hand circumference (A)	152	178	203	229	254	279
Hand length (B)	160	171	182	192	204	215

The above measurements are in accordance with AS/NZS 2161:2000, AS/NZS 2161.2:2005 (EN 420:2003)



uvex quick guide to glove sizing

For a more accurate measure please follow the instructions set out on the right. The above chart is a quick reference only.