
Arm & Body Protection

You may need to order one size larger when wearing arm guards over shirt sleeves, in which case we recommend measuring over your clothes. Having someone assist you will ensure accurate measurements.

How to Measure

- Neck: Measure the circumference where a standard button-down type collar would be fastened.
- Bicep: Measure around the widest part, a few inches below the shoulder.
- **Chest:** Measure the circumference at the fullest point, keeping the tape horizontal around the body.
- Sleeve length: Measure the distance from the prominent bone in the center on the back of the neck, across the shoulder, over the bent elbow, to the wrist bone.



Product	6/XS	7/S	8/M	9/L	10/XL	11/XXL	12/3XL
AG8TW	n/a	Length 9.1cm Wrist 20.3cm Width 25.4cm	Length 19.7cm Wrist 20.3cm Width 25.4cm	Length 21.6cm Wrist 22.9cm Width 27.9cm	Length 23.5cm Wrist 24.1cm Width 31.8cm	Length 25.4cm Wrist 25.4cm Width 35.6cm	Length 25.4cm Wrist 31.8cm Width 40.6cm
AG10009S, AG10009V	Length 24.1cm Wrist 21.6cm Width 31.1cm	Length 24.1cm Wrist 22.9cm Width 33.0cm	Length 26.0cm Wrist 26.0cm Width 36.2cm	Length 26.7cm Wrist 29.2cm Width 38.1cm	Length 27.9cm Wrist 35.6cm Width 43.2cm	Length 27.9cm Wrist 35.6cm Width 44.5cm	Length 31.1cm Wrist 36.8cm Width 45.7cm
1010	n/a	Length 41.1cm Wrist 17.8cm Bicep 37.5cm	Length 45.7cm Wrist 21.6cm Bicep 41.9cm	Length 48.3cm Wrist 24.1cm Bicep 48.3cm	Length 50.8cm Wrist 27.3cm Bicep 51.4cm	Length 53.3cm Wrist 30.5cm Bicep 55.9cm	n/a